



- A) Sensor pocket must have a flat rough surface
- B) Locate sensor pocket on punch center line
- C) 1/8 inch chamfer
- D) If width is greater than 4 inches use 1.125" as the dimension of the pocket

PROCESS TECHNOLOGIES GROUP, INC.

IMPAX®

TITLE: TRIM WEDGE FOR NATIONAL BOLTMAKER

DRAWN BY: CHRIS SMITH

DATE: 10/26/97

DRAWING NUMBER: NAT-CS-004